

Agilent U1251A and U1252A Handheld Digital Multimeter Quick Start Guide



The following items are included with your multimeter:

- ✓ Standard Test Lead Kit (test leads, alligator clips, SMT grabbers, fine tip test probes, mini-grabber)
- ✓ Soft carrying case
- ✓ Printed Quick Start Guide
- ✓ CD containing the User's Guide, application software and instrument drivers
- ✓ 9 V alkaline battery (for U1251A only)
- ✓ Rechargeable 7.2 V battery (for U1252A only)
- ✓ Power cord & AC adapter (for U1252A only)
- ✓ Certificate of Calibration

If anything is missing, contact your nearest Agilent Sales Office.

WARNING

Ensure the terminal connections are correct for that particular measurement before any measurement. To avoid damaged to the device, do not exceed the input limit.




Agilent Technologies

Performing Voltage Measurement

Measuring AC Voltage

- 1 Set the rotary switch to $\sim v$. For mV and mV mode, press **SHIFT** to ensure \sim is shown on the display.
- 2 Connect the red and black test leads to input terminals **V. mV(red)** and **COM(black)** respectively.
- 3 Probe the test points and read the display.
- 4 Press **DUAL** to display dual measurements. Parameter can be switched consecutively.




Measuring DC Voltage

- 1 Set the rotary switch to v and mV . Ensure --- is shown on the display.
- 2 Connect the red and black test leads to input terminals **V. mV(red)** and **COM(black)** respectively.
- 3 Probe the test points and read the display.
- 4 Press **DUAL** to display dual measurements. Parameter can be switched consecutively.

Performing Current Measurement

Measuring AC Current

- 1 Set the rotary switch to $\mu\text{A}\sim$ and $\text{mA}\sim$. Press **SHIFT** to ensure \sim is shown on the display.
- 2 Connect the red and black test leads to input terminals **$\mu\text{A}.\text{mA}$ (red)** and **COM(black)** or **A(blue)** and **COM(black)** respectively.
- 3 Probe the test points in series with the circuit, and read the display.



Measuring DC Current



- 1 Set the rotary switch to μA and mA . Ensure --- is shown on the display.
- 2 Connect the red and black test leads to input terminals **$\mu\text{A}.\text{mA}$ (red)** and **COM(black)** or **A(blue)** and **COM(black)** respectively.
- 3 Probe the test points in series with the circuit, and read the display.

CAUTION

- If the current is $\leq 440 \text{ mA}$, connect the red and black test leads to input terminals **$\mu\text{A}.\text{mA}$ (red)** and **COM(black)**.
- If the current is $> 440 \text{ mA}$, connect the red and black test leads to input terminals **A(blue)** and **COM(black)**.

Performing Resistance, Conductance and Testing Continuity Measurements


- 1 Set the rotary switch to **nS Ω** .
- 2 Connect the red and black test leads to input terminals **Ω (Red)** and **COM(black)** respectively.
- 3 Probe the test points (by shunting the resistor) and read the display.
- 4 Press **SHIFT** to scroll through audible continuity, conductance and resistance tests as shown.



Performing Capacitance and Temperature Measurements

Capacitance

- 1 Set the rotary switch to **TEMP**.
- 2 Connect the red and black test leads to input terminals **TEMP** (red) and **COM**(black) respectively.
- 3 Use the red probe lead on the positive terminal of the capacitor while the black probe lead on the negative terminal.
- 4 Read the display.



Temperature

- 1 Turn the rotary switch to **TEMP** position. Press **SHIFT** to select temperature measurement.
- 2 Plug the thermocouple adapter (with the thermocouple probe connected to it) into input terminals **TEMP**(red) and **COM**(black).
- 3 Touch the measurement surface with the thermocouple probe.
- 4 Read the display.

Frequency and Frequency Counter Measurements

Frequency Measurement


During AC/DC voltage or AC/DC current measurements, you can measure the relevant frequency by pressing **Hz** at anytime.

Frequency Counter Measurement

- 1 Set the rotary switch to **Hz**.
- 2 Press **SHIFT** to select the frequency counter (Hz) function. “—1—” on the secondary display means the input signal frequency is divided by 1. This accommodates for higher frequency range of up to 2 MHz.
- 3 Connect the red and black test leads to input terminals **V(red)** and **COM(black)** respectively.
- 4 Probe the test points and read the display.
- 5 If the reading is unstable or zero, press **RANGE** to select division of input signal frequency by 100. This accommodates for higher frequency range of up to 20 MHz.
- 6 The signal is out of specification if the reading is still unstable after Step 5.

WARNING

Use the frequency counter for low voltage application. Never use the frequency counter on line power system.




Square Wave Output (for U1252A only)


- 1 Turn the rotary switch to **JUNK % OUT ms** position. Default display setting is 600 Hz on secondary display and 50% duty cycle on primary display.
- 2 Press **◀** or **▶** to scroll through the available frequencies (there are 28 frequencies to choose from).
- 3 Press **SHIFT** to select duty cycle (ms) on primary display.
- 4 Press **▲** or **▼** to adjust the duty cycle. Duty cycle can be set for 256 steps and each step is 0.390625%. The display only indicates the best resolution with 0.001%.

NOTE

Pressing **Hz** is the same as pressing **▶**.



Features and Functions




Actions	Steps
Turns ON backlight	Press
Checks battery capacity	Press and hold for > 1 s
Freezes the measured value	Press
Starts MIN/MAX/AVG recording	Press and hold for > 1s
Offsets the measured value	Press
Changes the measuring range	Press
Turns on auto range	Press and hold for > 1 s
Turns on dual display	Press
Starts manual data logging	Press and hold for > 1s
Views the logged data	Press for > 1s, press to scroll through the logged data
Clears the logged data	Press for > 1 s, press for > 1 s


Input Terminals and Overload Protection

Measurement Functions	Input Terminal	Overload Protection
Voltage		1000 V R.M.S.
Diode		
Resistance		
Capacitance		
Temperature		
μA & mA	μA mA	440 mA/1000 V 30 kA/fast-acting fuse
A	A	11A/1000 V 30 kA/fast-acting fuse

Tilt Stand



Tilt Stand at 60°



Tilt Stand at 30°

Safety Information

This meter is safety-certified in compliance with EN/IEC 61010-1:2001, UL 61010-1 Second Edition and CAN/CSA 22.2 61010-1 Second Edition, Category III 1000 V Overvoltage Protection, Pollution Degree II. Use with standard or compatible test probes.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

Safety Symbols

CAT III
1000 V



Category III 1000 V Overvoltage
Protection



Double insulation



Earth ground



Caution, risk of danger



Caution, risk of electric shock

For further safety information details, refer to the **Agilent U1251A and U1252A Handheld Digital Multimeters User's and Service Guide**.

Printed in Malaysia



U1251-90002

©Agilent Technologies, Inc. 2006, 2007
Third Edition, October 15, 2007



Agilent Technologies